




SUMMIT AUTOMATION

PREMIER DOOR & WINDOW AUTOMATION SYSTEMS

DIP SWITCH FUNCTIONS



1. TURNS OFF ALL CURRENT LIMIT

2. CURRENT ADJUSTMENT FOR EVEREST MOTOR
IF USING AN EVEREST MOTOR TURN DIP 2 ON.

3. MOTION SENSOR, OR EYEBALL BI-PASS
IF USING MOTION SENSORS, OR TO BI-PASS EYE-BALLS TURN DIP 3 ON.

4. TBD

5. TBD

6. TBD

7. APEX SYSTEM MASTER CONTROL BOX

*IF USING AN APEX SYSTEM TURN ON DIP SWITCH 7
ON ONE CONTROL BOX MAKING IT THE MASTER.*

8. HARD SYSTEM RESET

CLEARs ALL SYSTEM MEMORY.